

extract from Videophone Installation Guide

The full Installation Guide can be downloaded from our website: www.konnekt.com.au/support.
Useful information and answers to common questions can be found here: www.konnekt.com.au/faq

Wall Mounting (using a Konnekt Bracket)

IMPORTANT: Observe the installation and safety instructions supplied with your bracket. The following guidelines supplement the bracket instructions. Use a stud finder or similar to ensure you don't drill into electrical wiring.

- Remove the Videophone kick-stand
 - unplug the power cable from the Videophone
 - place Videophone face down onto a flat surface, with a cloth underneath it to protect the Videophone screen if necessary
 - remove the 2 screws holding the kick-stand in place, and gently remove the kick-stand



- Attach the bracket backpiece to the Videophone
 - follow the instructions that come with your bracket of choice, and attach the applicable bracket backpiece to the back of the Videophone (M4 screws in a 100mm VESA pattern)
 - do not overly tighten, or you will damage the Videophone plastic housing
 - for 180 deg Tilt / Pan Bracket, use the four supplied washers, as shown below

Slimline Bracket backpiece



Tilt / Pan Bracket backpiece

- Tighten all screws using the allen key provided. This includes the tilt/pan mechanism itself, which involves tightening 3 screws. The mechanism should be stiff enough to hold the Videophone in place, while still permitting adjustment of viewing angle by the user.



180 deg Tilt / Pan Bracket backpiece

- Use the 4 washers supplied to distribute safely pressure onto backplate.
- Use the supplied tool to adjust the hex bolt at the rear of the main swivel joint. It should be stiff enough to hold the Videophone in place, while permitting adjustment by the user.

CAUTION: If this bolt is too stiff, Videophone damage will occur when you try to adjust!



- Drill any holes in walls / ceilings required for cable routing.
- Route cables carefully, to avoid cable damage when brackets are moved. Some brackets come with cable straps to hold cables in place.
- Mark, drill, and attach the applicable bracket component to the wall.

NOTES:

Tilt / Pan and 180 deg Tilt / Pan Brackets MUST be mounted onto a stud, or into brick or similar. Slimline Brackets are not adjustable, so carefully check that the installation will be level.

- Mount Videophone onto bracket.

Custom Bracket

You can supply your own bracket to suit the requirements of your particular Videophone user and location. The Videophone has a standard VESA mounting pattern, and can therefore be used with a wide range of brackets, including ...

- TV brackets
- computer monitor brackets
- specialised hospital grade brackets, designed to attach to a bed or chair
eg. TeleTidy www.teletidy.com.au/

Ensure you source a bracket to suit the following

- the Videophone has a standard VESA 100mm x 100mm mounting hole pattern at the rear
- the Videophone weighs 5.6kg
- the Videophone dimensions are (in mm): 400 x 316 x 69