

## extract from Videophone Installation Guide

The full Installation Guide can be downloaded from our website: [www.konnekt.com.au/support](http://www.konnekt.com.au/support).  
Useful information and answers to common questions can be found here: [www.konnekt.com.au/faq](http://www.konnekt.com.au/faq)

### Desk / Table Mounting

- Fold out the rear kick-stand, and position the Videophone at intended location.
- Note the location of the middle of the rear of the kick-stand, and thoroughly clean and then dry the desk/table surface there.
- Remove cover from adhesive pad of Adhesive Desk Clamp.
- Position Adhesive Desk Clamp with cable clamp lock facing away from Videophone, underneath the rear kick-stand. Stick it onto the desk/table, and hold in place for 30-60 seconds to secure.

- Secure the rear of the kick-stand by passing the cable clamp through the lock ...
  - making it very tight will inhibit movement of the Videophone and provide the most security
  - making it a bit looser will enable the user to slightly adjust the Videophone position
  - if you wish, you can use a small screw to fix the cable clamp to the desk/table for additional security and safety

